

LASSI Data Analysis Pipeline V2

March 6, 2019

1 LASSI Data Analysis Pipeline V2

This is an updated attempt to create a pipeline that illustrates how one would take Leica scanner data and produce commands to the Active Surface Manager that would compensate for any detected surface deformations. The parts of this pipeline that need work we'll mark in red TODOs.

1.1 Summary

Our pipeline consists of these basic steps:

- preliminary trimming and rotation of data from PTX file
- smoothing of data in spherical coordinates
- fitting each of the reference and signal scans to parabolas
- regridding data to be in same reference frame
- finding displacements in signal scan by finding residuals
- fitting zernikes to this new surface
- converting zernikes to the proper notation
- sending zernikes to Active Surface manager

The current issues and problematic parts include:

- smoothing step is *far* too slow - 10 hours per scan. But we have already made progress converting these to GPUs, and there are other alternatives we are also looking into.
- are we really achieving the desired accuracy?
- we believe we are converting results correctly to zernike commands expected by Active Surface, but we really won't know till we try it

In [1]: `#!/matplotliblib notebook`

1.2 Step One: Get some Leica data for a reference and signal scan

We are still unclear on how we are going to do this for production. What we are currently using as input are PTX files (human readable) that were produced by Leica employees (using in part at least, the Cyclone software).

Copies of these files can be in: `/home/sandboxes/pmargani/LASSI/data`.

According to Brian Elbe, all he did to produce these files was import the data into Cyclone, removed 'unwanted' parts of the image (presumably the ground), then export it to PTX. Should be easy to replicate.

The files are further processed by our own Mathematica code that was adapted from some of Fred's work.

This code does a simple Affine Transform, and filters out things like the header and data that is past a certain distance from the scanner. It can also optionally take a random sample of the PTX data to avoid working with the full data set.

It will write the final output to a file name of your choosing.

The source for this can be found here: /home/sandboxes/pmargani/LASSI/data/LeicaP40demo/Aug2016/1

TODO: We are currently porting this to Python, but are hung up on a question we need answered from Fred.

1.3 Step Two: Smooth this Data

Warning: this is the computationally expensive part! We've already done this step, which takes about 10 hours for each scan, so we highly recommend you don't run this commented code, and instead use the dumps we made of this smoothing to file.

TODO: we need to find a way to make this processing faster by this summer (2019).

```
In [2]: # Don't run this! For 512x512, using ALL the data (not a random sampling)
        # this could take 10 hours for each scan
        # from main import *
        #n = 512
        #fn1 = "data/randomSampleSta10.csv"
        #x1, y1, z1 = smoothSpherical(fn1, n)
        #fn2 = "data/randomSampleBumpScan14.csv"
        #x2, y2, z2 = smoothSpherical(fn2, n)

        # instead the smoothed data can be found here:
        # fn1 = "data/BumpScan.csv.smoothed.sig.001.all.npz"
        # fn = "data/Baseline_STA10_HIGH_METERS.csv.smoothed.sig.001.all.npz"
```

1.4 Step Three: Fit this data to parabolas

We'll leverage our parabolas module to do the heavy lifting here. See also the 'Parabolas' and 'Show me the Bumps' Notebooks.

We also have a unit test class, TestParabolas.py, which demonstrates the limits of our parabolas toolbox.


```
In [3]: from parabolas import *
        fn = "data/Baseline_STA10_HIGH_METERS.csv.smoothed.sig.001.all.npz"
        refDiff, refX, refY = fitLeicaScan(fn)
```



```
cleaned data fitted with coefficients: [ 5.74103825e+01  2.83550388e-01 -2.22811412e+00 -4.9179
1.52444697e-03 -3.31407039e-02]
```


```
/data/sandboxes/pmargani/lassi-analysis/pmargani_lassi_env/lib/python2.7/site-packages/numpy/core
return ufunc.reduce(obj, axis, dtype, out, **passkwargs)
```

```
In [4]: fn = "data/BumpScan.csv.smoothed.sig.001.all.npz"
        bumpDiff, bumpX, bumpY = fitLeicaScan(fn)
```

```
cleaned data fitted with coefficients: [ 5.74057921e+01  2.87711772e-01 -2.22274546e+00 -4.9178
 1.43249224e-03 -3.30739453e-02]
```








1.5 Step Four: Regrid the data to both be in the same evenly spaced x, y

Both so that both scans are in the same x, y space, and also in preparation for fitting zernikes to the results, we need to regrid our scans. They were evenly spaced in spherical coordinated, but are now unevenly spaced in x, y, which is why the images above look like guitar picks and not dishes. This is the problem we are fixing in this step.


```
In [5]: # Don't run this code now: it takes about 20 minutes for each scan!
# bumpXs, bumpYs, bumpDiffs = smoothXYZDask(bumpX, bumpY, bumpDiff, 512, sigX=0.1, sigY=
# refXs, refYs, refDiffs = smoothXYZDask(refX, refY, refDiff, 512, sigX=0.1, sigY=0.1)


# instead we can load the saved results
refDiffs = np.load("refDiffsSmoothed.npy")
refXs = np.load("refXsSmoothed.npy")
refYs = np.load("refYsSmoothed.npy")
bumpXs = np.load("bumpXsSmoothed.npy")
bumpYs = np.load("bumpYsSmoothed.npy")
bumpDiffs = np.load("bumpDiffsSmoothed.npy")

In [6]: imagePlot(refDiffs, "ref scan smoothed")
```



```
In [7]: imagePlot(bumpDiffs, "bump scan smoothed")
```






These images don't tell us much, but if we were to smooth the log of the difference of one of these scans, we'll see a familiar image:

1.6 Step Five: Find the Deformations

Also known as, 'Show me the Bumps'. This step is conceptually simple: we just find the difference between our reference and signal scan. We break it out in a separate step here for dramatic affect.

```
In [8]: diffData = refDiffs - bumpDiffs
        diffDataLog = np.log(np.abs(diffData))
        imagePlot(diffDataLog, "Surface Deformations")
```



Step five and a half: open some beers.

1.7 Step Six: Fit Zernikes to this surface

This is identical to what we did in the first version of our pipeline. But note, that we're still not sure that we want to do this on this data: we probably need put this image on a unit circle?



TODO: Determine what else might need to be done to image before fitting zernikes.

```
In [9]: import opticspy
        from copy import copy
        import numpy as np

        # replace NaNs with zeros
        diffDataOrg = copy(diffData)
        diffDataLog[np.isnan(diffDataLog)] = 0.

        # find the first 12 Zernike terms
        numZsFit = 36
        fitlist, C1 = opticspy.zernike.fitting(diffDataLog,
                                              numZsFit,
                                              remain2D=1,
                                              barchart=1)

        print "fitlist: ", fitlist
        C1.listcoefficient()
        C1.zernikemap()
```

Zernike Polynomials List

Z1	Z2	Z3	Z4	Z5	Z6	Z7	Z8	Z9	Z10	
0.000	-0.306	0.171	0.468	-0.028	-0.309	-0.153	0.072	0.053	0.027	
Z11	Z12	Z13	Z14	Z15	Z16	Z17	Z18	Z19	Z20	
0.365	-0.182	-0.067	-0.037	0.015	0.074	-0.025	-0.053	0.023	0.030	
Z21	Z22	Z23	Z24	Z25	Z26	Z27	Z28	Z29	Z30	
-0.097	0.540	0.080	-0.100	-0.021	-0.057	-0.014	-0.014	0.118	0.048	
Z31	Z32	Z33	Z34	Z35	Z36	Z37				
-0.080	-0.078	0.090	-0.027	0.013	-0.020	0.000				

fitlist: [0, 0, -0.306, 0.171, 0.468, -0.028, -0.309, -0.153, 0.072, 0.053, 0.027, 0.365, -0.182, -0.067, -0.037, 0.015, 0.074, -0.025, -0.053, 0.023, 0.030, -0.097, 0.540, 0.080, -0.100, -0.021, -0.057, -0.014, -0.014, 0.118, 0.048, -0.080, -0.078, 0.090, -0.027, 0.013, -0.020, 0.000]

Z2 = -0.306 Z11 x Tilt

Z3 = 0.171 Z11 y Tilt

Z4 = 0.468 Z20 Defocus

Z5 = -0.028 Z22 Primary Astigmatism at 45

Z6 = -0.309 Z22 Primary Astigmatism at 0

Z7 = -0.153 Z31 Primary y Coma

Z8 = 0.072 Z31 Primary x Coma

Z9 = 0.053 Z33 y Trefoil

Z10 = 0.027 Z33 x Trefoil

Z11 = 0.365 Z40 Primary Spherical

Z12 = -0.182 Z42 Secondary Astigmatism at 0

Z13 = -0.067 Z42 Secondary Astigmatism at 45

Z14 = -0.037 Z44 x Tetrafoil

Z15 = 0.015 Z44 y Tetrafoil

Z16 = 0.074 Z51 Secondary x Coma

Z17 = -0.025 Z51 Secondary y Coma

Z18 = -0.053 Z53 Secondary x Trefoil

Z19 = 0.023 Z53 Secondary y Trefoil

Z20 = 0.03 Z55 x Pentafoil

Z21 = -0.097 Z55 y Pentafoil

Z22 = 0.54 Z60 Secondary Spherical

Z23 = 0.08 Z62 Tertiary Astigmatism at 45


Z24 = -0.1 Z62 Tertiary Astigmatism at 0

Z25 = -0.021 Z64 Secondary x Trefoil

Z26 = -0.057 Z64 Secondary y Trefoil

Z27 = -0.014 Z66 Hexafoil Y

Z28 = -0.014 Z66 Hexafoil X
 Z29 = 0.118 Z71 Tertiary y Coma
 Z30 = 0.048 Z71 Tertiary x Coma
 Z31 = -0.08 Z73 Tertiary y Trefoil
 Z32 = -0.078 Z73 Tertiary x Trefoil
 Z33 = 0.09 Z75 Secondary Pentafoil Y
 Z34 = -0.027 Z75 Secondary Pentafoil X
 Z35 = 0.013 Z77 Heptafoil Y
 Z36 = -0.02 Z77 Heptafoil X
 Z2 = -0.306 Z11 x Tilt
 Z3 = 0.171 Z11 y Tilt
 Z4 = 0.468 Z20 Defocus
 Z5 = -0.028 Z22 Primary Astigmatism at 45
 Z6 = -0.309 Z22 Primary Astigmatism at 0
 Z7 = -0.153 Z31 Primary y Coma
 Z8 = 0.072 Z31 Primary x Coma
 Z9 = 0.053 Z33 y Trefoil
 Z10 = 0.027 Z33 x Trefoil
 Z11 = 0.365 Z40 Primary Spherical
 Z12 = -0.182 Z42 Secondary Astigmatism at 0
 Z13 = -0.067 Z42 Secondary Astigmatism at 45
 Z14 = -0.037 Z44 x Tetrafoil
 Z15 = 0.015 Z44 y Tetrafoil
 Z16 = 0.074 Z51 Secondary x Coma
 Z17 = -0.025 Z51 Secondary y Coma
 Z18 = -0.053 Z53 Secondary x Trefoil
 Z19 = 0.023 Z53 Secondary y Trefoil
 Z20 = 0.03 Z55 x Pentafoil
 Z21 = -0.097 Z55 y Pentafoil
 Z22 = 0.54 Z60 Secondary Spherical
 Z23 = 0.08 Z62 Tertiary Astigmatism at 45
 Z24 = -0.1 Z62 Tertiary Astigmatism at 0
 Z25 = -0.021 Z64 Secondary x Trefoil
 Z26 = -0.057 Z64 Secondary y Trefoil
 Z27 = -0.014 Z66 Hexafoil Y
 Z28 = -0.014 Z66 Hexafoil X
 Z29 = 0.118 Z71 Tertiary y Coma
 Z30 = 0.048 Z71 Tertiary x Coma
 Z31 = -0.08 Z73 Tertiary y Trefoil
 Z32 = -0.078 Z73 Tertiary x Trefoil
 Z33 = 0.09 Z75 Secondary Pentafoil Y
 Z34 = -0.027 Z75 Secondary Pentafoil X
 Z35 = 0.013 Z77 Heptafoil Y
 Z36 = -0.02 Z77 Heptafoil X



1.8 Step Seven: Convert the coefficients from Noll to ANSI

Recall that opticspy works in Noll notation, while the Active Surface Manager seems to work in a modified version of ANSI (offset by one, phase rotated by 90 degrees). Whether this is the only conversion needed to be done is another remaining open question.

```
In [10]: from zernikeIndexing import noll2asAnsi, printZs
         # why does the fitlist start with a zero? for Z0?? Anyways, avoid it
         nollZs = fitlist[1:(numZsFit+1)]
         asAnsiZs = noll2asAnsi(nollZs)
         print "nolZs"
         printZs(nollZs)
         print "active surface Zs"
         printZs(asAnsiZs)
```

```
nolZs
[0]
[-0.306, 0.171]
[0.468, -0.028, -0.309]
[-0.153, 0.072, 0.053, 0.027]
[0.365, -0.182, -0.067, -0.037, 0.015]
[0.074, -0.025, -0.053, 0.023, 0.03, -0.097]
[0.54, 0.08, -0.1, -0.021, -0.057, -0.014, -0.014]
[0.118, 0.048, -0.08, -0.078, 0.09, -0.027, 0.013, -0.02]
active surface Zs
[0]
[-0.306, 0.171]
[-0.309, 0.468, -0.028]
[0.027, 0.072, -0.153, 0.053]
[-0.037, -0.182, 0.365, -0.067, 0.015]
[0.03, -0.053, 0.074, -0.025, 0.023, -0.097]
[-0.014, -0.057, -0.1, 0.54, 0.08, -0.021, -0.014]
[-0.02, -0.027, -0.078, 0.048, 0.118, -0.08, 0.09, 0.013]
```

1.9 Step Eight: Send these Coefficients to the Active Surface Manager

The Active Surface Manager has the `zernike_coeff` parameter (indexes 1 through N). When these are set, the manager can use them to compute the displacement of each individual actuator.

However, one has to have everything setup correctly and have the right permissions, so we won't simply call it from here. Instead, here's the instructions: * save `asAnsiZs` to numpy file


* decide which telescope you want to use (real, sim?) * use the new ActiveSurfaceDevice.py
here: /home/sandboxes/pmargani/sparrow/master3/sparrow/gbt/api/ygor/src * python ActiveSurfaceDevice.py



1.10 Conclusions



If we look at the results we got, how do they compare to what the active surface was really commanded to during it's bump scan?



```
In [11]: from surfaceZoom import *  
         analyzeZooms(diffData, diffDataLog)
```



```
top panel: mean=-3.212015e-04 std=8.726966e-05  
top surface: mean=1.433711e-04 std=1.353458e-04  
middle panel: mean=8.250688e-04 std=7.682750e-05  
bottom surface: mean=-1.371779e-04 std=7.329503e-05  
bottom panel: mean=-5.929281e-05 std=9.306090e-05
```


























In []:

